

## ■ 取扱説明書

本製品をお買い上げ頂きまして誠にありがとうございます。  
安全に使用して頂くため、必ず説明書をよくお読みのうえ正しくご使用ください。  
また、お読み頂いた後も、この説明書は大切に保管してください。

## ■ Instruction


Read this instruction manual and make sure you thoroughly understand its contents before using this product.  
This product is designed and manufactured for use in Japan only.  
We bear no responsibility for any damages or losses arising from use of, or inability to use, this product outside Japan and provide no technical support or after-service for this product outside Japan.  
The importer shall translate this instruction manual into the appropriate language for the users of this product.  
The distributor shall make the users of this product understand the contents of this instruction manual.

## ■ ご使用前に

- ・本製品は自転車用のロックです。本来の用途以外に使用しないでください。
- ・品質には万全を期しておりますが、使用前に破損が無いか確認してください。
- ・本製品が破損した場合は、使用しないでください。
- ・梱包用の袋は、乳幼児や小さなお子さまにとって窒息の危険がともないます。開封後は速やかに処分してください。

## ■ 各部名称

ロック本体



## ■ 製品仕様

サイズ：W35 x D9.5 x H34 mm (ロック本体のみ)

ワイヤー長：φ3 x 900 mm


材質：亜鉛合金 (ロック本体)

スチール、PVC (ケーブル)


原産国：台湾

## ■ 番号設定方法

- ① ダイアルを "000" に設定しロックを解除します。
- ② シャックルが右図のように閉じている状態で、リセットボタンを押し込みながらダイアルをお好みの番号に回します。  
※シャックルが開いた状態だとリセットボタンを押し込むことができません。
- ③ リセットボタンを元に戻し、設定完了です。
- ④ 番号が任意の番号で設定されているか確認後、ご使用ください。  
※設定番号は必ずメモを残すなどして、忘れないようにしてください。



ロック本体  
底面



リセットボタン

## ■ 使用、安全上の注意事項

- ・直射日光があたる車の中やお風呂場などの湿度の高い場所に放置しないでください。
- ・濡れたり、汚れたまま放置すると腐蝕の原因となります。きれいに拭き取ってから保管してください。
- ・高所から落とすなど、強い衝撃を加えないでください。破損の原因となります。
- ・本製品を改造しないでください。
- ・本製品は完全な盗難防止を保証するものではありません。
- ・盗難されにくくするため、2重施錠や建造物など動かせないものに施錠するなどの手段を推奨します。