

■ 取扱説明書

本製品をお買い上げ頂きまして誠にありがとうございます。
安全に使用して頂くため、必ず説明書をよくお読みのうえ正しくご使用ください。
また、お読み頂いた後も、この説明書は大切に保管してください。


■ Instruction

Read this instruction manual and make sure you thoroughly understand its contents before using this product.
This product is designed and manufactured for use in Japan only.
We bear no responsibility for any damages or losses arising from use of, or inability to use, this product outside Japan and provide no technical support or after-service for this product outside Japan.
The importer shall be translate this instruction manual into the appropriate language for the users of this product.
The distributor shall make the users of this product understand the contents of this instruction manual.

■ ご使用前に

- ・本製品は自転車用サドルです。それ以外の用途に使用しないでください。
- ・品質には万全を期しておりますが、使用前に破損が無いか確認してください。
- ・本製品が破損した場合は、使用しないでください。
- ・梱包用の袋は、乳幼児や小さなお子さまにとって窒息の危険がともないます。開封後は速やかに処分してください。

■ 各部名称 / 使用方法



■ 製品仕様

座面サイズ：幅 約212mm、全長 約250mm
シートレール間隔：43mm
重量：約570g
材質：張り材 - PVC
シートレール - スチール
クッション - エラストマー
原産国：中国

■ 取付方法

1. お使いのシートポストのクランプを緩め、サドルを取外します。
2. シートレールとクランプが噛み合っていることを確認し、一度仮止めをします。
3. サドルの角度と前後の位置を調整し、規定のトルクで締め付けます。



注意

傷害を負う可能性または物的損害のみが発生する可能性が想定される内容を示しています。

- ・取付後に必ず、サドルがしっかりと固定されているか確認してください。装着が不十分ですと走行中にサドルが外れる可能性があり、大変危険です。
- ・本製品の取付・交換に際しまして、技術・経験が必要です。専門知識・設備を有する専門店、自転車販売店に取付をご依頼ください。
- ・取付時に生じた汚損・破損については保証の対象外となります。
- ・直射日光は避けてください。劣化や色あせの原因となります。